

FTT Elevated Temperature Oxygen Index Spare Parts List

<i>Part No</i>	<i>Part type</i>	<i>Part Name</i>	<i>Notes</i>
P041-4	Burner	Ignition burner assembly	Igniter application tube and regulating valve.
HP016-4	Chimney	Restrictor cap	
HP021-3	Chimney	Column assembly	
HP043-3	Chimney	Pre-heater assembly	
HP029-4	Debris tray	Debris tray	
HP999	Manual	User's guide for Elevated Temperature Oxygen Index	
HP026-4	Sample	Film rolling tool	
P023-4	Sample	Specimen holder for materials of forms I to IV (rigid)	
P040-4	Sample	Specimen holder for materials of form V (sheet)	
P036-4	SRM	Perspex reference sample including certificate (pack of 10)	OI=17.4 pack of 10
P039-4	SRM	ASTM Perspex reference sample including certificate (pack of 10)	As per ASTM D 2863
HP033	Thermocouple	Sample thermocouple	
HP034	Thermocouple	Pre-heater thermocouple	
HP035	Thermocouple	Column thermocouple	
HP028-4	Tool	Specimen transfer device	
HP031-4	Tool	Debris tray placement adaptor	